
Tel:+8675527390189 Web:www.grilite.com Fax:+8675527397337 Contact: sales@grilight.com

COB480LED/m-DC24V-5MM

SPECIFICATION



480 m

240

Voltage

5 ••

FPC width



Power

Product features:

- Any cut, easy to use, more accurate installation
- High-quality double-sided copper FPC board, flexible and resistant to bending, strong and durable
- High-density COB chips, soft light and brighter light
- 120° illumination angle, high CRI, no spot, no flicker
- IP20 is not waterproof (can be processed to customize IP65\IP67\IP68 protection level)
- Precise production, quality assurance, 5-year warranty
- Support special customization and sample customization













Application:

Widely used in hotels, shoppingmalls, furniture, cabinets, shelf as decoration lighting, direct lighting or indirect lighting



















Product parameters:

General parameters	
Product Model	GL-R1000TF-480SxCOB COB 480leds/meter
Color	WW, NW, CW
сст	2700K/3000K/4000K/6000K (Special CCT can be customized)
CRI	Ra≥90
Beam angle	120°
Cut Distance	8.3mm
Environmental test parameters	
IP grade	IP20
Working environment	-25℃~+45℃
Storage environment	-30℃~+80℃
Max connection Length	5m

Performance parameters	
Lumen(±5%)	540~600lm/m
Efficiency(±5%)	90~100lm/W
Voltage	DC24V
Electric current	250mA/m
Power	6W/m
Packaging parameters	
A roll	5m
N.W(Roll)	80g
Qty/Carton	500m-100roll
Packing size(mm)	L720*W280*H410
G.W	9Kg
















Processing custom waterproof process:














Package:




Installation diagram:



Clean the installation surface




Measure the length you need toinstall, cut at the nearest scissor mark line.




Tear off the double-sided adhesive tape on the back and paste it in a suitable position

For the left led strip, weld at the next scissor mark to connect with other connection wire.



Connect the light strip wire to the driver output port (positive pole to positive pole, negative pole to negative pole)



Turn on the power switch after confirming that the line is connected

Statements:

- 1). For safety, the product wire should be moved and replaced by the manufacturer, agent or other authorized person.
- 2). Please refer to the product manual before installation.
- 3). Above-refered schematic diagrams are from our standard product. Please subject to your actual product data if there is difference.
- 4). In actual use, we suggest 80% consumption of the driver. Keep 20% as power to start the led strip.
- 5). For safety, no touch the AC terminal.
- 6). Any acidic or alkaline substance is forbidden.
- 7). No notice for updated of this product.









No power supply Give power supply. Automatic switch-off because of the open circuit and short circuit Wrong connection (positive connect with negative) Part power-supply fail Part circuit error Part wrong connection(positive connect negative) Vector and make sure the power supply well. Check and get right connection. Check and get right connection. Very beginning to the driver Very beginning to the switch, or unbalanced power consumption of the switch, or unbalanced power consumption from different strip series. Too big power consumption from different strip series. Too big power consumption from different strip unbalanced power consumption from different strip unbalanced power consumption from different strip unbalanced power series similar). Too many Led strips connection Adjust the led strip quantity, make sure sufficient power supply.			
All fail Automatic switch-off because of the open circuit and short circuit Wrong connection (positive connect with negative) Part power-supply fail Part circuit error Part wrong connection(positive connect negative) Ocheck and get right connection. Check and get right connection. Use higher-power driver. Keep the strip working voltage is more or less 5% than the Rated voltage. 1.shorten the connection cable length, or change to thicker cable. 2.Make sure the tonnection cable length, or change to thicker cable. 2.Make sure the strip quantity is less than the allowed connection quantity. Keep the led strip quantity of each series similar). Too many Led strips connection Adjust the led strip quantity make sure sufficient power supply. Poor welding connection of wires Check, find and solve it.	Problem	Possible reasons	solution
Solve the problem, switch on again. Wrong connection (positive connect with negative) Part power-supply fail Part circuit error Part wrong connection(positive connect negative) Veck and get right connection. Check and get right connection. Veep the strip working voltage is more or less 5% than the Rated voltage. 1. shorten the connection cable length, or change to thicker cable. 2. Make sure the strip quantity is less than the allowed connection quantity. Keep the led strip quantity of each series similar). Too many Led strips connection Adjust the led strip quantity make sure sufficient power supply. Poor welding connection of wires Check, find and solve it.	All fail	No power supply	Give power supply.
Part fail Part power-supply fail Part circuit error Part wrong connection(positive connect negative) Overload of the driver Too big power consumption of the switch, or unbalanced power consumption from different strip series. Too many Led strips connection Part wrong connection(positive connect negative) Check and get right connection. Keep the strip working voltage is more or less 5% than the Rated voltage. 1.shorten the connection cable length, or change to thicker cable. 2.Make sure the strip quantity is less than the allowed connection quantity. Keep the led strip quantity of each series similar). Too many Led strips connection Adjust the led strip quantity, make sure sufficient power supply. Poor welding connection of wires Check, find and solve it.		•	Solve the problem, switch on again.
Part fail Part wrong connection(positive connect negative) Overload of the driver Use higher-power driver. Keep the strip working voltage is more or less 5% than the Rated voltage. 1. shorten the connection cable length, or change to thicker cable. 2. Make sure the strip quantity is less than the allowed connection puantity. Keep the led strip quantity of each series similar). Too many Led strips connection Adjust the led strip quantity, make sure sufficient power supply. Poor welding connection of wires Check, find and solve it.		Wrong connection (positive connect with negative)	Check and get right connection.
Part circuit error Part wrong connection(positive connect negative) Overload of the driver Use higher-power driver. Keep the strip working voltage is more or less 5% than the Rated voltage. 1.shorten the connection cable length, or change to thicker cable. 2.Make sure the strip quantity is less than the allowed connection quantity. Keep the led strip quantity of each series similar). Too many Led strips connection Adjust the led strip quantity, make sure sufficient power supply. Poor welding connection of wires Check, find and solve it.	Part fail	Part power-supply fail	' '
Inconsistent brightness or insuffiscent brightness Too many Led strips connection Too many Led strips connection Overload of the driver Use higher-power driver. Keep the strip working voltage is more or less 5% than the Rated voltage. 1.shorten the connection cable length, or change to thicker cable. 2.Make sure the strip quantity is less than the allowed connection quantity. Keep the led strip quantity of each series similar). Too many Led strips connection Adjust the led strip quantity, make sure sufficient power supply. Poor welding connection of wires Check, find and solve it.		Part circuit error	
Inconsistent brightness or insuffiscent brightness Too big power consumption of the switch, or unbalanced power consumption from different strip series. Too big power consumption of the switch, or unbalanced power consumption from different strip series. Keep the strip working voltage is more or less 5% than the Rated voltage. 1.shorten the connection cable length, or change to thicker cable. 2.Make sure the strip quantity is less than the allowed connection quantity. Keep the led strip quantity of each series similar). Too many Led strips connection Adjust the led strip quantity, make sure sufficient power supply. Poor welding connection of wires Check, find and solve it.		Part wrong connection(positive connect negative)	Check and get right connection.
Inconsistent brightness or insuffiscent brightness Too big power consumption of the switch, or unbalanced power consumption from different strip series. Too big power consumption of the switch, or unbalanced power consumption from different strip series. 2. Make sure the strip quantity is less than the allowed connection quantity. Keep the led strip quantity of each series similar). Too many Led strips connection Adjust the led strip quantity, make sure sufficient power supply. Poor welding connection of wires Check, find and solve it.	Inconsistent brightness or insuffiscent brightness	overload of the driver	Use higher-power driver.
Foor welding connection of wires Poor welding connection of wires Check,find and solve it.		unbalanced power consumption from different strip	or less 5% than the Rated voltage. 1.shorten the connection cable length, or change to thicker cable. 2.Make sure the strip quantity is less than the allowed connection quantity. Keep the led strip quantity of
LED flash		Too many Led strips connection	
	LED flash	Poor welding connection of wires	Check,find and solve it.
		switch problem	Change to right switch.